

# Advanced Noise Reduction Techniques and Improvements

Robert E. Ryan Mary Pagnutti Kara Holekamp Innovative Imaging and Research Building 1103 Suite 140 C Stennis Space Center, MS 39529


JACIE/ASPRS 2014 Louisville, KY March 27, 2014

## What is Denoising & Why?

- Denoising is the process of removing noise hopefully without removing information.
  - Edge Preserving Filters
    - Bilateral Filter (Common)
    - Nonlocal Means
    - Sparse Methods (Computationally Intensive)
      - Wavelet
      - SVD
      - DCT Based
      - •
- Improved spatial resolution, increased coverage and acquiring imagery over wider illumination conditions generally decrease SNR

## Digital Camera Radiometric Performance

Smaller detectors are needed to keep the sensor size down but decreases SNR if GSD is to be reduced



## Extending the Imaging Envelope

 Terrestrial optical imaging visible-near infrared (no thermal) in low natural and artificial lighting

#### Why?

- Disaster response for hurricanes, fires, earth quakes, tsunamis, etc. desire all weather all condition imagery
- Human activity (mapping artificial lights)
- Light pollution(environmental, astronomy & energy)
- Improved cloud statistics



Standard Pan Sharpened Image


Solar Elev. 0°




\*\*\*\*\*\*\*\*\*\*\*\*

Solar Elev. 0°


~ 1-2 Minutes after sunset



~5 minutes past sunset



Imagery acquired ~10 minutes past sunset




Standard Pan Sharpened Imagery

45 minutes after sunset



## General Denoising Approach




#### **Noise Estimation**

- The noise level is needed to set noise thresholds
- Noise depends on both signal levels and sensor characteristics
  - Adaptive noise estimation techniques are needed that work on the imagery of interest

## Laboratory Estimation of Noise

- Integrating sphere images can be used estimate variance vs. DN
- Integrating Spheres acquired at different apertures provided imagery at varying DN levels
  - Mean DN and variance values were estimated using a 3x3 moving window
  - Values were grouped into 100DN wide bins and average variance per bin was found
  - Binned DN and variance data from all apertures was combined
- A linear curve fit through the combined binned variance data provided the relationship between DN level and noise


# Absolute Radiometric Calibration System




## Integrating Sphere Images

- Used to flat field images and measure SNR
- Note SNR will depend on location


Flat Fielding Image2D FPA




## 036 Red Band




### 036 Green Band




### 036 Blue Band



### 036 NIR Band





## Noise Estimation Using Discrete Transforms






DCT Method Enables Measurement of Noise In Presence of Structure







## Implementation and Evaluations

- Several selected denoising algorithms were implemented and optimized parameters were determined
  - Exact single band bilateral filter adaptive noise
  - DCT Patch algorithm
- Algorithms were applied to Aerial images from different acquisitions for testing

#### Bilateral Filter

- Bilateral filtering is a method of smoothing images that combines two separate types of filtering
  - Spatial filter weights pixels in the neighborhood surround a center pixel based on distance
    - Gaussian function used for spatial filtering
  - Intensity filter weights neighborhood pixels based on the similarity of intensity values
    - Preserves edges by only allowing pixels with similar intensity values to be included in the spatial filter
    - Intensity filter parameter closely related to image noise
- Operates on each band of an image independently

#### General Bilateral Filter Formulation2

#### Spatial Filter

$$G(p) = \frac{\iint I(q) \ D(q,p) \ dq}{\iint D(q,p) \ dq}$$

- Where I is the input image, p is the neighborhood center pixel, and D is a function of Euclidean distance between pixel q and the center pixel p
- Intensity Filter

• 
$$F(p) = \frac{\iint I(q) R(I(q),I(p)) dq}{\iint R(I(q),I(p)) dq}$$

- Where R is a function of the image intensity between values at neighborhood pixel q and center pixel p
- Combined Bilateral Filter

$$B(p) = \frac{\iint I(q) \ D(q,p) \ R(I(q),I(p)) \ dq}{\iint D(q,p) \ R(I(q),I(p)) \ dq}$$

### Implemented Gaussian Bilateral Filter2

#### Gaussian Spatial Function

$$D(q,p) = e^{-\left(\frac{(x-c)^2 + (y-r)^2}{2\sigma_D^2}\right)}$$

• Where, (x,y) and (r,c) are the image row/column locations of pixels q and p, and the standard deviation,  $\sigma D$ , defines the width of the gaussian function

#### Gaussian Intensity Function

$$R(I(q),I(p)) = e^{-\left(\frac{(I(q)-I(p))^2}{2\sigma_R^2}\right)}$$

• Where, I(q) and I(p) are the image intensity values at pixels q and p, and the standard deviation,  $\sigma R$ , defines the width of the intensity range


#### Bilateral Filter

$$B(p) = \frac{\sum_{q} I(q) D(q,p) R(I(q),I(p))}{\sum_{q} D(q,p) R(I(q),I(p))}$$


#### Bilateral Filter Test Parameters

- Test edge
  - 51 x 51 pixels (= neighborhood size)
  - Maximum image intensity (DN) = 1000
- Image noise varied between 2 and 4 % of maximum DN
- $\bullet$   $\sigma_D$  varied between 5 and 10
- $\bullet$   $\sigma_R$  varied between 1, 2, and 5 times the image noise


## Test Edge – $\sigma_D = 5$ Image Noise = 2% of Max




## Test Edge – $\sigma_D = 10$ Image Noise = 2% of Max DN



## Test Edge – $\sigma_D = 5$ Image Noise = 4% of Max DN



## Test Edge – $\sigma_D = 10$ Image Noise = 4% of Max DN



## Example Image Results

Sample areas taken from Stennis and Wbroad images

# Exact Bilateral Filter with Adaptive Noise

**Filtered** Unfiltered

## DCT Patch with Adaptive Noise

**Filtered** Unfiltered

## Exact Bilateral Filter with Adaptive Noise

Unfiltered Filtered




Unfiltered Filtered




# Exact Bilateral Filter with Adaptive Noise

Unfiltered Filtered



Unfiltered Filtered




# Exact Bilateral Filter with Adaptive Noise





# Exact Bilateral Filter with Adaptive Noise


**Filtered** Unfiltered



## DCT Pan Filtering Examples

DMCII Low Light data acquired over Columbus OH

GSD: 36 cm (MS) and 17.6cm (pan)











#### Summary

- Smaller GSD and extended imaging envelopes are driving the SNR
- Denoising techniques can improve final product without significantly blurring the imagery
  - Traditional Bilateral & Sparse Methods can be used on high resolution imagery to improve SNR
  - Adaptive intra-image noise estimation techniques are needed